

LAWN-BOY®

Walk-Behind Power Mower

GoldPro Series™

Model No. 10424, 10525, 10547 — 9900001 & Up

Operator's Manual

Para obtener una versión gratis de este manual en español, escriba a la dirección indicada más abajo. Asegúrese de indicar el modelo y el número de serie de su producto.

Pour obtenir gratuitement une version en français de ce manuel, écrivez à l'adresse ci-dessous. N'oubliez pas d'indiquer les numéros de modèle et de série de votre produit.

Lawn-Boy Inc., Attn: Parts Dept., 8111 Lyndale Ave S, Bloomington, MN 55420-1196.

Contents


	Page
Introduction	2
Safety	3
Safe Operating Practices	3
Safety and Instruction Decals	5
Assembly	5
Handle	5
Cover Plate	6
Battery (Model 10547)	7
Before Starting	7
Oil Mix Ratio	7
Mixing Gasoline And Oil	8
Lawn Preparation And Mowing	9
Operation	10
Starting Engine	10
Stopping Engine	10
Self-propelled Drive	11
Adjusting Cutting Height	11
Mulching Tips	12
Maintenance	13
Recommended Maintenance Schedule	13
Air Filter	14
Spark Plug	14
Clean Mower Housing	15
Blade	15
Lubrication	17
Self-propelled Cable	18
Exhaust Ports	18
Battery (Model 10547)	19
Troubleshooting	20
Accessories	21
Rear Grass Catcher	21
Mulch Plate	23
Storage	24
Fuel	24
Engine	24
Folding Handle	25
Removing From Storage	25
Warranty	Back Cover

Introduction

Thank you for purchasing a Lawn-Boy product.

All of us at Lawn-Boy want you to be completely satisfied with your new product, so feel free to contact your local Authorized Service Dealer for help with service, genuine Lawn-Boy parts, or other information you may require.

Whenever you contact your Authorized Service Dealer or the factory, always know the model and serial numbers of your product. These numbers will help the Service Dealer or Service Representative provide exact information about your specific product. You will find the model and serial number decal located in a unique place on the product as shown below.



1149

1. Model and Serial Number Decal

For your convenience, write the product model and serial numbers in the space below.

Model No: _____

Serial No. _____

Read this manual carefully to learn how to operate and maintain your product correctly. Reading this manual will help you and others avoid personal injury and damage to the product. Although Lawn-Boy designs, produces and markets safe, state-of-the-art products, you are responsible for using the product properly and safely. You are also responsible for training persons who you allow to use the product about safe operation.

The Lawn-Boy warning system in this manual identifies potential hazards and has special safety messages that help you and others avoid personal injury, even death. DANGER, WARNING and CAUTION are signal words used to identify the level of hazard. However, regardless of the hazard, be extremely careful.

DANGER signals an extreme hazard that will cause serious injury or death if the recommended precautions are not followed.

⚠
WARNING
⚠

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

WARNING signals a hazard that may cause serious injury or death if the recommended precautions are not followed.


CAUTION signals a hazard that may cause minor or moderate injury if the recommended precautions are not followed.

Two other words are also used to highlight information. “Important” calls attention to special mechanical information and “Note” emphasizes general information worthy of special attention.

The left and right side of the machine is determined by standing behind the handle in the normal operator’s position.



The 2-stroke engine provided on this product meets the EPA Phase I Non-Road Emissions regulations for engines under 19 KW. This product does not comply to CARB TIER 1 regulations and cannot be sold in California.

Safety

This machine meets or exceeds CPSC blade safety requirements for walk-behind rotary mowers and the B71.1 specifications of the American National Standards Institute, in effect at time of production. However, improper use or maintenance by the operator or owner can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety alert  symbol which means **CAUTION, WARNING or DANGER**—“personal safety instruction.” Failure to comply with the instruction may result in personal injury.

Safe Operating Practices

This product is capable of amputating hands and feet and throwing objects. Always follow all safety instructions to avoid serious injury or death.

 WARNING 
POTENTIAL HAZARD <ul style="list-style-type: none">• Engine exhaust contains carbon monoxide, which is an odorless, deadly poison.
WHAT CAN HAPPEN <ul style="list-style-type: none">• Carbon monoxide can kill you and is also known to the State of California to cause birth defects.
HOW TO AVOID THE HAZARD <ul style="list-style-type: none">• Do not run engine indoors or in an enclosed area.

This mower is designed for cutting and mulching grass or, when equipped with a grass bag, for catching cut grass. Any use for purposes other than these could prove dangerous to user or bystanders.

Note: This engine is NOT equipped with a spark arrester muffler. Use or operation of this mower in the State of California on any forest-covered, brush-covered or unimproved grass-covered land, without an approved spark arrester muffler, is a violation of the law. Other states may have similar laws.

General Operation

1. Read this manual carefully before operating the mower. Become familiar with the controls and proper use of the mower. Never allow children under 16 years of age to operate the mower. Never allow adults to operate mower without proper instructions.
2. The operator of the mower is responsible for keeping everyone, especially children and pets, away from area of operation. The operator is responsible for accidents or hazards occurring to other people or their property.
3. Thoroughly inspect area where mower will be used and remove sticks, stones, wire, and debris. Watch for foreign objects while mowing.
4. Wear long pants and substantial shoes. Do not operate mower while wearing open-toed shoes, jewelry, loose clothing or when barefoot.
5. Check fuel level before starting engine. Do not fill fuel tank indoors, when the engine is running, or until engine cools for several minutes after running. Do not smoke while refueling. Wipe up spilled gasoline before starting engine.
6. Keep all guards, shields, grass catchers and safety devices in place. Repair or replace damaged parts, including decals. Check all safety devices before each use.
7. Engine, blade and self-propelled drive are designed to stop when control bails are released. Ensure control and brake function properly before each use of mower.
8. Because fuel is highly flammable, handle it carefully.
 - A. Use an approved container.

B. Fill fuel tank outdoors, not indoors. **NEVER ADD FUEL TO AN ENGINE THAT IS RUNNING OR HOT.**

C. Install gas cap on fuel container and gas tank, and wipe up any spilled gasoline before starting engine.

9. Before using, always visually inspect to see that the blades, blade bolts and cutter assembly are not worn or damaged. Replace worn or damaged blades and bolts in sets to preserve balance.

While Operating

1. Do not run engine indoors.
2. Do not upend mower when starting engine. If necessary, tilt mower so that blade points away from operator and bystanders.
3. Start the engine carefully according to instructions and with feet well away from the blade.
4. Always maintain secure footing. Keep a firm grip on the handle and walk; never run. Never operate mower in wet grass. Mow only in daylight or in good artificial light.
5. Mow across the face of slopes; never up and down. Use extreme caution when changing direction on slopes. Do not mow excessively steep slopes. Wear skid resistant shoes on slopes.
6. Always wear safety glasses or eye shields during operation to protect eyes from foreign objects that may be thrown from the machine.
7. Keep face, hands, and feet away from the mower housing and cutter blade when the engine is running. Blade can cause injury to hands and feet.
8. Use extreme caution when reversing or pulling the mower toward you.
9. Stay behind the handle until the engine stops and keep clear of discharge opening at all times.
10. When bagging grass, stop engine and stay behind handle until all moving parts stop before removing and emptying bag.
11. When mowing, ensure grass bag or mulch plate is installed over discharge opening.
12. Shut engine off and stay behind handle until all moving parts stop before unclogging chute.
13. Since the blade rotates for a few seconds after the blade control bail is released, stay behind the handle until all moving parts stop.
14. After striking a foreign object or if mower vibrates abnormally, stop engine and remove wire from spark plug. Check mower for damage and make all repairs

before using mower again. If major repairs are ever needed or if assistance is desired, contact your local Authorized Lawn-Boy Service Dealer.

15. Stop the engine and wait for all moving parts to stop before adjusting the height-of-cut.
16. Stop the blade when pushing the mower outside the lawn area.
17. Stop engine before leaving the operator's position — behind the handle. Disconnect wire from spark plug if mower will be unattended.
18. Do not touch engine while it is running or shortly after it is stopped because engine will be hot enough to cause a burn.
19. If mower must be lifted to be transported, turn off engine and stay behind the handle until all moving parts stop.

Maintenance

1. Perform only those maintenance instructions described in this manual. If major repairs are ever needed or if assistance is desired, contact your local Authorized Lawn-Boy Service Dealer.
2. Before mower is cleaned, inspected, serviced, or adjusted, stop engine and disconnect wire from spark plug. Keep wire away from plug to prevent accidental starting.
3. To assure the mower is in safe operating condition, frequently check and keep all nuts, bolts, and screws tight. Assure blade nut is tightened to 560 in.-lbs. (47 ft.-lbs.) (63 N·m).
4. When servicing blade, refer to blade maintenance section for correct installation and servicing procedures.
5. To reduce fire hazard, keep engine free of excessive grease, grass, leaves, and accumulations of dirt.
6. Do not overspeed the engine by changing governor settings.
7. Check grass catcher bag frequently for wear or deterioration. Replace with a new bag when worn or damaged for your protection.
8. Allow engine to cool before storing mower in any enclosure. Do not store mower near any open flame or where gasoline fumes may be ignited by a spark.
9. At the time of manufacture, the mower conformed to the safety standards in effect for rotary mowers. To ensure best performance and continued safety certification of the mower, use genuine Lawn-Boy replacement parts and accessories. Replacement parts and accessories made by other manufacturers may result in nonconformance with the safety standards, and that could be dangerous.


Safety and Instruction Decals




Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or lost.




ON MOWER HOUSING
(Part No. 43-8480)



ON MOWER HOUSING
(Part No. 93-7250)



ON CONSOLE
(Part No. 98-4469, Model 10525)



ON CONSOLE
(Part No. 98-4468, Model 10547)

Assembly

Handle

Assembly

1. Loosen handle knobs and lift top handle half in an arc until handle halves are in line and nest together (Fig. 1).

Note: Use care to prevent pinching or stretching of cables.

2. Tighten knobs securely.
3. Rotate handle toward rear of mower.




Figure 1

1. Knob
2. Top handle half

Handle Height

Handle may be placed in three (3) operating positions, high, medium or low (Fig. 2). Select a handle height position that is most comfortable for you.




Figure 2

- | | |
|-------------------|---------------------------|
| 1. High setting | 5. Traction cable bracket |
| 2. Medium setting | 6. Traction cable spring |
| 3. Low setting | 7. Actuator bracket |
| 4. Mower housing | |

1. Align holes in lower handle section with holes in mower housing. Using hardware shown in Figure 2, secure handle to mower housing.

(Self-propelled Models Only)

1. Hook traction cable spring into actuator bracket as shown in Figure 2.
2. Match three (3) holes in traction cable bracket to three (3) holes in left side of mower housing. Secure bracket with handle hardware (Fig. 2).

Cover Plate

Your mower was shipped with a cover plate (Fig. 4). For side discharge operation the plate must be installed into deck opening.

! **WARNING** !

POTENTIAL HAZARD

- An uncovered discharge opening will allow objects to be thrown in operator's or bystander's direction. Also, contact with blade could occur.

WHAT CAN HAPPEN

- Thrown objects or blade contact can cause serious injury.

HOW TO AVOID THE HAZARD

- Never operate mower unless cover plate, mulch plate or grass chute and catcher are installed.

1. Stop engine and disconnect spark plug wire (Fig. 3) before installing or removing cover plate.




Figure 3

1. Spark plug wire

2. Remove knob that fastens cover plate to the housing (Fig. 4).




Figure 4

1. Cover plate
2. Knob

- Two shoulder bolts on the housing protrude through slotted holes in the cover plate and do not have to be loosened or removed. Cover plate moves over the shoulder bolt heads (Fig. 5).




Figure 5

- Shoulder bolt

- Slide cover plate clockwise to install or counterclockwise to remove.
- Secure with knob.
- Connect spark plug wire (Fig. 3).

Battery (Model 10547)

A new battery must be charged for 72 continuous hours to ensure full charge.

- Charge battery. See MAINTENANCE chapter, Charging Battery section for instructions.
- Connect leads from starter motor to battery (Fig. 6).




Figure 6

- Battery
- Leads

- Insert key into switch on control panel when you are ready to start the engine (Fig. 7).




Figure 7

- Key

Before Starting Oil Mix Ratio

Your Lawn-Boy mower is powered by a 2-cycle engine which requires a 32:1 mixture of gasoline and oil. Use **only Lawn-Boy® GENERATION II 2-Cycle Ashless Oil, packaged in purple/green cans (Fig. 8) or an equivalent premium grade 2-cycle ashless oil, certified NMMA TCW III.** Failure to use the correct oil or mixture ratio could result in serious engine damage.



Figure 8

Lawn-Boy Generation II 2-Cycle Ashless Oil is formulated specifically for Lawn-Boy and is available from your Lawn-Boy retailer. Regular use of Lawn-Boy Generation II 2-Cycle Ashless Oil will help keep your engine clean, reduce spark plug fouling, piston ring sticking and pre-ignition. Lawn-Boy Generation II 2-Cycle Ashless Oil will also minimize varnish build-up, combustion chamber deposits and exhaust port blockage.

If Lawn-Boy Generation II 2-Cycle Ashless Oil is not available, other premium grade 2-cycle ashless oils, certified NMMA TCW III, can be substituted. Substitute oils may produce more exhaust smoke and may require increased engine service including more frequent spark plug changes, exhaust port/cylinder decarbonizing, and could reduce engine life.

IMPORTANT: ONLY Lawn-Boy® Generation II 2-Cycle Ashless Oil, packaged in purple/green cans or an NMMA TCW III certified oil should be used.

Note: NEVER USE AUTOMOTIVE OIL (i.e. SAE 30, 10W30 etc.), OR THE WRONG MIX RATIO BECAUSE ENGINE DAMAGE MAY OCCUR. If engine failure occurs and it has been determined that Lawn-Boy Generation II 2-Cycle Ashless Oil or an NMMA TCW III certified oil was not used, the failure may not be covered by the Lawn-Boy warranty.

!DANGER!

POTENTIAL HAZARD

- In certain conditions gasoline is extremely flammable and highly explosive.

WHAT CAN HAPPEN

- A fire or explosion from gasoline can burn you, others, and cause property damage.

HOW TO AVOID THE HAZARD

- Use a funnel and fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any gasoline that spills.
- Do not fill the fuel tank completely full. Add gasoline to the fuel tank until the level is 1/4" to 1/2" (6 mm to 13 mm) below the bottom of the filler neck. This empty space in the tank allows gasoline to expand.
- Never smoke when handling gasoline, and stay away from an open flame or where gasoline fumes may be ignited by a spark.
- Store gasoline in an approved container and keep it out of the reach of children.
- Never buy more than a 30-day supply of gasoline.

!DANGER!

POTENTIAL HAZARD

- In certain conditions gasoline is extremely flammable and highly explosive.

WHAT CAN HAPPEN

- A fire or explosion from gasoline can burn you, others, and cause property damage.

HOW TO AVOID THE HAZARD

- Always place gasoline containers on the ground away from your vehicle before filling.
- Do not fill gasoline containers inside a vehicle or on a truck or trailer bed because interior carpets or plastic truck bed liners may insulate the container and slow the loss of any static charge.
- When practical, remove gas-powered equipment from the truck or trailer and refuel the equipment with its wheels on the ground.
- If this is not possible, then refuel such equipment on a truck or trailer from a portable container, rather than from a gasoline dispenser nozzle.
- If a gasoline dispenser nozzle must be used, keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete.

Mixing Gasoline And Oil

For simplicity and best engine performance, mix 8 ounces (250 ml) of Lawn-Boy Generation II 2-Cycle Ashless Oil with two gallons (8 liters) of fresh, unleaded regular gasoline. Pour one gallon (4 liters) of gasoline into an approved gasoline container and add the correct amount of 2-cycle oil. Install cap on gasoline container and shake to mix oil and gasoline thoroughly (Fig. 9). Slowly remove cap and add remaining gasoline.




Figure 9

1056

Note: Do not mix gasoline and oil in the product fuel tank. Oil that is at room temperature mixes easily and more thoroughly than cold oil.

Use clean, fresh lead-free gasoline with an octane rating of 85 or higher. Purchase only the quantity of gasoline that can be used in 30 days to assure freshness. Use of lead-free gasoline results in fewer combustion chamber deposits and longer spark plug life. Leaded gasoline may be used if lead-free is not available.

Note: NEVER USE METHANOL, GASOLINE CONTAINING METHANOL, GASOHOL CONTAINING MORE THAN 10% ETHANOL, PREMIUM GASOLINE OR WHITE GAS BECAUSE ENGINE FUEL SYSTEM COULD BE DAMAGED.

1. Clean around fuel cap before removing (Fig. 10). Fill fuel tank with gasoline/oil mix to within 1/4 inch (6.5 mm) of top of tank, not into filler neck. **DO NOT OVER-FILL TANK.** Replace fuel cap securely and wipe up any spilled fuel.




Figure 10

Lawn-Boy recommends that Lawn-Boy 2+4® Fuel Conditioner (Fig. 11) be used regularly during operation and storage. Lawn-Boy 2+4® Fuel Conditioner cleans the engine during operation and prevents gum-like varnish deposits from forming in the engine during storage.



Figure 11

1058

DO NOT USE FUEL ADDITIVES OTHER THAN THOSE MANUFACTURED FOR FUEL STABILIZATION DURING STORAGE, SUCH AS LAWN-BOY 2+4® FUEL CONDITIONER. LAWN-BOY DOES NOT RECOMMEND STABILIZERS WITH AN ALCOHOL BASE SUCH AS ETHANOL OR METHANOL. STABILIZERS SHOULD NOT BE USED TO TRY TO ENHANCE THE POWER OR PERFORMANCE OF MACHINE.

2. Connect spark plug wire (if disconnected) (Fig. 12).




Figure 12

1. Spark plug wire


Lawn Preparation And Mowing

1. Review SAFETY INSTRUCTIONS and read this manual carefully before operating mower.
2. Clear area of sticks, stones, wire, branches and other debris which could be picked up or hit by cutting blade and become thrown objects.
3. Keep everyone, especially children and pets, away from area of operation.
4. Avoid striking trees, walls, curbs or other solid objects. Never deliberately mow over any object.
5. If an object is struck, or mower starts to vibrate, immediately stop engine, disconnect spark plug wire and examine mower for damage.
6. Replace blade when necessary with an original Lawn-Boy replacement blade.

Operation

Starting Engine

Note: Follow steps in BEFORE STARTING section.

1. Move throttle lever to  position (Fig. 13).





Figure 13

1. Throttle lever

2. Push primer three (3) times (Fig. 14). Wait about two (2) seconds between each push.

Note: Do not use  position to restart a warm engine after a short shutdown.





Figure 14

1. Primer

3. Hold blade control bail against upper handle (Fig. 16).

4. Start mower.

A. ELECTRIC STARTING (Model 10547)—Turn key clockwise to START  position (Fig. 15).




Figure 15

1. Key

B. MANUAL STARTING (All models)—Pull starter handle (Fig. 16) lightly until resistance is felt, then pull sharply. Let rope return to handle slowly.








Figure 16


1. Blade control bail
2. Upper handle
3. Starter handle


5. If the engine fails to start, repeat steps 2 through 4.

Note: If the engine starts but then begins to stall, move the throttle lever to the  position until the engine continues to run, then move the throttle back to the  position.

In cool temperatures, it may be necessary to prime three times with the throttle lever in the  position, and then start the engine. Once the engine has started, move the throttle lever to the  position.

Stopping Engine

1. Move throttle lever to  position (Fig. 13).
2. Release blade control bail (Fig. 17). Both the engine and blade will stop. See your dealer immediately if they do not.




1046

Figure 17

1. Blade control bail

3. For model 10547, remove key from switch if mower will be unattended or not used.

To Restart Engine

1. Repeat STARTING ENGINE procedure with throttle lever in  position.

Note: To restart a warm engine, a single prime may be required, but do not push the primer button any more than once, or you may flood the engine.

Self-propelled Drive


(self-propelled models only)

1. Move ground speed lever to one (1) of three (3) ground speeds, **1** – slow, **2** – medium or **3** – fast. Select a speed that is comfortable to walk and not too fast for grass length.

Note: Do not change ground speeds with self-propelled drive engaged. Stop mower, place ground speed lever in desired position, then continue mowing.

2. Move ground speed lever to N – neutral when trimming or leaving mower.
3. To operate self-propelled drive squeeze self-propelled bail against handle and hold (Fig. 18).

Note: Slight variations in ground speed can be made by increasing space between self-propelled bail and handle.




1048

Figure 18

1. Self-propelled bail

4. To disengage self-propelled drive, release self-propelled bail (Fig. 19).

Note: Mower is equipped with free-wheeling clutches which make it easier to pull the mower rearward. To disengage clutches mower may need to be pushed forward one inch or more after self-propelled bail has been released.





1047

Figure 19

1. Self-propelled bail

Adjusting Cutting Height

Each wheel is adjusted individually with a wheel height adjustment lever. Cutting heights are 1", 1-1/2", 2", 2-1/2", 3" and 3-1/2 inches (25, 38, 51, 64, 74 and 86 mm).

	DANGER	
POTENTIAL HAZARD		
<ul style="list-style-type: none"> • Adjusting height-of-cut levers could bring hands into contact with moving blade. 		
WHAT CAN HAPPEN		
<ul style="list-style-type: none"> • Contact with rotating blade can cause serious injury. 		
HOW TO AVOID THE HAZARD		
<ul style="list-style-type: none"> • Stop engine and wait for all movement to stop before adjusting cutting height. • Do not put fingers under housing when adjusting height-of-cut. 		

1. To change cutting height pull wheel height adjustment lever toward wheel and move to the desired position (Fig. 20).




Figure 20

1. Wheel height adjustment lever
-
2. Release wheel height adjustment lever and seat securely in notch.

Note: Set all four (4) wheels at the same height.

Mulching Tips

General Tips

Follow these instructions whether cutting grass or leaves for the best cutting results and lawn appearance:

- Maintain a **sharp blade** throughout the cutting season. Periodically file down nicks on blade.
- Only mow dry grass or leaves. Wet grass and leaves tend to clump on yard and may cause mower to plug or engine to stall. They may also be slippery to walk on and could cause you to slip and fall.

	WARNING	
POTENTIAL HAZARD		
<ul style="list-style-type: none"> • Wet grass or leaves can cause you to slip and contact blade. 		
WHAT CAN HAPPEN		
<ul style="list-style-type: none"> • Blade contact can seriously injure you. 		
HOW TO AVOID THE HAZARD		
<ul style="list-style-type: none"> • Mow only in dry conditions. 		

- Set engine speed to fastest position. Maximum horsepower provides best cutting results.
- Clean clippings or leaves from underside of mower deck after each mowing.
- Keep engine in good running condition. Cutting and recutting requires more horsepower.
- Clean air filter more frequently. Cutting and recutting stirs up more clippings and dust which clogs the air filter and reduces engine performance.

Cutting Grass

- Grass grows at different rates at different times of the year. In the heat of summer, it is generally best to cut grass at the 2, 2.5 or 3 inch height-of-cut settings. Only about 1/3 of the grass blade should be cut off. Cutting below the 2 inch setting is not recommended unless grass is sparse or it is late fall when grass growth begins to slow down.
- When cutting grass over six inches tall, you may want to first mow using the highest height-of-cut setting and a slower walking speed; then mow again at a lower setting for best lawn appearance. If grass is too long and leaves clumps on top of lawn, mower may plug and cause engine to stall.
- Alternate mowing direction. This helps disperse clippings over lawn for even fertilization.

If the finished cut lawn appearance is unsatisfactory, try one or more of the following:

- Sharpen the blade.
- Walk at a slower pace while mowing.
- Raise the height-of-cut setting on your mower.
- Cut grass more frequently.
- Overlap cutting swaths instead of cutting a full swath with each pass.

Cutting Leaves

- When cutting is complete, always be sure that 50% of the lawn shows through the cut leaf cover. This may require one or more passes over the leaves.
- Walk at a slower mowing speed if leaves are not being cut up finely enough to be hidden down in the grass.
- If you cut up a lot of oak leaves, you might want to add lime to your grass in the spring. Lime reduces the acidity of oak leaves.

Maintenance

NOTICE: Maintenance, replacement, or repair of the emission control devices and systems may be performed by any nonroad engine repair establishment or individual. However, to obtain no charge repairs under the terms and provisions of the Toro warranty statement, any service or emission control part repair or replacement must be performed by an Authorized Toro Service Dealer.

Continued safe and dependable operation requires routine maintenance.

Recommended Maintenance Schedule

Service Item	Service Operation	After every use	5 Hours	25 Hours	48 Hours	50 Hours	100 Hours
Housing	Clean built-up grass clippings and dirt.	X					
Fasteners	Check blade and engine mounting fasteners frequently. Keep all nuts, bolts and screws tight to ensure safe operation.		X				
Air Filter	Remove and clean each mowing season or every 50 hours. Clean more frequently if operating conditions are dusty.					X	
Spark Plug	Clean, inspect and gap. Replace if necessary.					X	
Lubrication	Grease rear height adjusters			X			
Battery (Model 10547)	Charge battery for 48 hours once every month or as required. Charge for 72 hours when mower is stored and in the spring before first mowing.				X		
Blade	Sharpen or replace; maintain more frequently if edge is dulled quickly in rough or sandy conditions.					X	
Blade Brake	Check stopping time every 50 hours or at start of each mowing season. Blade must stop within 3 seconds of releasing bail; if not see your Authorized Lawn-Boy Service Dealer for repair.					X	
Exhaust Ports	Clean every 100 hours.						X
Fuel System	Check for leakage and/or deterioration of fuel hose. Replace if necessary.					X	
Cooling System	Clean grass clippings, debris or dirt that clog engine air cooling fins and starter. Clean more frequently under dirty or high chaff conditions.						X



CAUTION



POTENTIAL HAZARD

- If you leave the wire on the spark plug, someone could start the engine.

WHAT CAN HAPPEN

- Accidental starting of engine could seriously injure you or other bystanders.

HOW TO AVOID THE HAZARD

- Pull the wire off of the spark plug before you do any maintenance. Also push the wire aside so that it does not accidentally contact the spark plug.

Air Filter

Clean air filter once every season or every 50 hours; **clean more frequently under dusty conditions.**

Note: Do not operate engine without air filter element; extreme engine wear or damage will occur.

1. To remove air filter, snap cover latch open and swing to side (Fig. 21).




Figure 21

1. Filter
2. Cover

2. Remove air filter.
3. Wash air filter in laundry detergent or kerosene (Fig. 22).
4. Squeeze filter to remove excess liquid and blot dry with a paper towel or rag.




Figure 22

988

5. Apply one tablespoon of SAE 30W oil to the air filter (Fig. 23).




Figure 23

989

6. Squeeze until oil is distributed evenly throughout filter. Blot lightly with paper towel to remove excess oil.
7. Replace filter with cleaner side facing carburetor.

Note: Be sure filter is fully seated in air box and does not pucker, allowing direct passage of air and dirt.

Spark Plug

A spark plug that is dirty, pitted, carbon-covered or has worn electrodes may cause hard starting and poor operation.

Replace spark plug once a season or clean every 50 hours, whichever occurs first. Use an NGK BPMR4A spark plug.

1. Pull wire off spark plug (Fig. 25). Remove key from switch.
2. Remove spark plug and clean with a wire brush, removing carbon build-up. **DO NOT SAND BLAST.** Check condition of plug for cracks and damaged or worn electrodes. Replace if necessary.
3. Set spark plug gap at .035 inch (.85 mm) (Fig. 24).




Figure 24

986

4. Install spark plug by hand, then torque to 180 in.-lbs. (15 ft.-lbs.) (20 N·m).
5. Reconnect spark plug wire when maintenance is completed (Fig. 25).




Figure 25

m-3833

1. Spark plug wire

Clean Mower Housing

A clean mower housing provides the best cutting performance. Check for grass build-up and clean after each use.

1. Run engine dry or remove gas with hand pump when the engine is cool.

! **WARNING** !

POTENTIAL HAZARD

- Gasoline is extremely flammable, highly explosive and under certain conditions can cause personal injury or property damage.

WHAT CAN HAPPEN

- Tipping mower may cause fuel leakage from carburetor or fuel tank.

HOW TO AVOID THE HAZARD

- Avoid fuel spills by running engine dry or remove gas with hand pump, never siphon.

2. Disconnect spark plug wire (Fig. 25).
3. Tip mower onto right side (Fig. 26).




Figure 26

1036

4. Scrape built-up grass clippings and dirt from mower housing with a hardwood scraper.
5. Reconnect spark plug wire when maintenance is completed.

Blade

A straight, sharp blade provides maximum cutting performance. Regularly inspect and sharpen blade.

! **WARNING** !

POTENTIAL HAZARD

- Blade is sharp.

WHAT CAN HAPPEN

- Contact with sharp blade can cause serious personal injury.

HOW TO AVOID THE HAZARD

- Wear gloves or wrap sharp edges of the blade with a rag.

Blade Straightness

1. Disconnect spark plug wire (Fig. 25).
2. Measure the distance from the bottom edge of the mower housing to the blade tip (Fig. 27). Rotate the blade 180° and measure to other blade tip.

Note: If measurements are not within 1/8 inch (3.2 mm), blade should be replaced. If, after blade replacement, the measurements are still not within 1/8 inch (3.2 mm), the crankshaft should be checked for straightness by your Authorized Lawn-Boy Service Dealer.




Figure 27

1005




Figure 28

1022

- | | |
|-----------------|-----------------|
| 1. Blade nut | 3. Blade |
| 2. Mulching fan | 4. Blade driver |

Blade Removal

1. Remove blade nut and mulching fan (Fig. 28).

2. Remove blade from blade driver (Fig. 28).
3. Examine blade cutting edges for nicks, cutting angle and sharpness. Sharpen or replace if necessary.
4. Examine mulch fan for worn or bent blades. Replace if necessary.
5. Examine blade driver for bent or sheared drive lugs. Replace if necessary.

Blade Sharpening

	WARNING	
POTENTIAL HAZARD		
<ul style="list-style-type: none"> • When sharpening blade, pieces of blade could be accidentally thrown. 		
WHAT CAN HAPPEN		
<ul style="list-style-type: none"> • Thrown objects can cause serious eye injury. 		
HOW TO AVOID THE HAZARD		
<ul style="list-style-type: none"> • Wear proper eye protection when sharpening blade. 		

1. Sharpen only the leading edge of blade with a file or grinder. Do not sharpen beyond the recommended area.

Note: Blade should not be ground more than 5 inches (127 mm) from outside ends and no less than 2 inches (51 mm) from trailing edge (Fig. 29).




Figure 29

990

Blade Balancing

1. Check the balance of blade by placing the center hole of blade over a nail or screwdriver shank clamped horizontally in a vise (Fig. 30).
2. If either end of blade rotates downward, grind or file that end (not the cutting edge). Blade is properly balanced when neither end drops.




Figure 30

1007

Blade Installation

1. Install blade driver onto crankshaft (if removed) (Fig. 28).
2. Locate blade over lugs of blade driver with curved ends toward mower housing.
3. Install mulch fan into blade recess and secure with blade nut (Fig. 31).




Figure 31

1024

4. Torque blade nut to 560 in.-lbs. (47 ft.-lbs.) (63 N·m).

Note: Blade nut must be replaced after installing and removing four (4) times. Locking feature will decrease and nut could loosen if not replaced.


5. Connect spark plug wire when maintenance is completed (Fig. 25).

Lubrication

Rear Height Adjusters

(self-propelled models only)

1. Wipe grease fittings on rear height-of-cut adjusters (Fig. 32) with a clean rag.
2. Install grease gun onto fitting and gently apply 1 or 2 pumps of #2 multi-purpose lithium grease. Excess grease may damage seals and prevent proper wheel clutch operation.



1018

Figure 32

1. Grease fitting


Self-propelled Cable

(self-propelled models only)

Whenever handle height is changed, a new self-propelled cable is installed or traction drive belt slips, adjustment is required.

Self-propelled cable is adjusted at the left handle bracket by moving cable jacket held by jam nuts.

1. Hold self-propelled bail 1 to 1½ in. (25 to 38 mm) from handle (Fig. 33).



1131

Figure 33

1. Cable jacket
2. Jam nut

2. Adjust jam nuts, at handle bracket, so cable is tight, but spring is not stretched.
3. Tighten jam nuts securely.
4. Release bail and check to see that cable is loose.

Note: Cable must be loose with bail in released position or mower may creep when bail is disengaged.

Exhaust Ports

Carbon deposit build-up causes excessive wear and loss of power. Check and clean them every 100 hours.

1. Remove spark plug. See SPARK PLUG section.
2. Drain gasoline using a hand pump.
3. Tip mower on its right side.



WARNING



POTENTIAL HAZARD

- Gasoline is extremely flammable, highly explosive and under certain conditions can cause personal injury or property damage.


WHAT CAN HAPPEN

- Tipping mower may cause fuel leakage from carburetor or fuel tank.

HOW TO AVOID THE HAZARD

- Avoid fuel spills by running engine dry or remove gas with hand pump, never siphon.

4. Remove blade nut, mulch fan and blade. See BLADE REMOVAL section.
5. Remove blade driver by tapping with plastic or fiber hammer in the direction of rotation (Fig. 34). This will loosen the blade driver from taper on crankshaft.



m-3835

Figure 34

1. Blade driver
6. Remove (4) capscrews attaching cover plate to engine mounting plate (Fig. 35).
7. Remove transfer pipe (Fig. 35).




Figure 35

m-3836

- | | |
|------------------|--------------------------------------|
| 1. Cover plate | 4. Exhaust port |
| 2. Cap screw | 5. High temperature silicone sealant |
| 3. Transfer pipe | |

8. Rotate crankshaft slowly until piston covers exhaust port (Fig. 35).

9. Using a wooden dowel, loosen carbon deposits by inserting dowel into port.

Note: Do not use metal tools; they could scratch piston.

10. Set mower upright.

11. Hold blade control bail against upper handle (Fig. 36) and pull starter rope several times to blow out loose carbon.




Figure 36

1348

- | | |
|-----------------------|-------------------|
| 1. Blade control bail | 3. Starter handle |
| 2. Upper handle | |

12. Run a bead of high temperature, automotive silicone sealant along the edge of the engine mounting plate where the cover plate will rest (Fig. 35).

13. Reinstall transfer pipe and cover plate (Fig. 35), torquing the (4) capscrews to 75 in lbs (8.5 N-m).

14. Attach blade driver, blade and mulch fan with blade nut. See **BLADE INSTALLATION**.
15. Torque blade nut to 560 in.-lbs. (47 ft.-lbs.) (63 Nm).
16. Tip mower upright.
17. Reconnect spark plug wire when maintenance is completed.
18. Fill fuel tank with clean, fresh gasoline.

Battery (Model 10547)

Charging Battery

A new battery must be charged for 72 continuous hours to ensure a full charge. Also, charge battery for 72 hours when mower is stored for a long period of time and in the spring before first mowing. Charge battery for 48 hours once every month or as required. **DO NOT OVERCHARGE.** The engine is equipped with an alternator which charges the battery during operation. Charging is not needed after each mowing.

1. Stop engine and pull wire off spark plug (Fig. 25). Remove key from switch.
2. Disconnect leads connecting starter motor to battery (Fig. 37).




Figure 37

1353

1. Leads

3. Connect charger supplied with your mower to battery and plug into 120VAC power outlet. After charging battery for specified time, unplug charger and disconnect from battery.

IMPORTANT: Only the Lawn-Boy charger is recommended because other chargers could damage the battery. Always use charger indoors and charge battery at room temperature (22°C or +70°F) whenever possible. Do not charge battery longer than 72 hours because damage could result.

Note: Disconnect battery from charger and mower during storage.

4. Reconnect leads from starter motor to battery.
5. Reconnect spark plug wire.

The incineration, landfilling or mixing of sealed lead (acid) batteries with the municipal solid waste stream is **PROHIBITED BY LAW** in some areas.

Return this battery to a federal or state approved sealed lead (acid) battery recycler. This may be where you purchased the battery.

Contact your local waste management officials for other information regarding the environmentally sound collection, recycling and disposal of this battery.



Disposing of Battery

DO NOT PLACE USED BATTERIES IN YOUR REGULAR TRASH!

THIS SEALED LEAD (ACID) BATTERY MUST BE COLLECTED, RECYCLED OR DISPOSED OF IN AN ENVIRONMENTALLY SOUND MANNER.

Troubleshooting


Your mower was designed and built for trouble-free operation. Check the following components and items carefully. If a problem continues, see your Authorized Lawn-Boy Service Dealer.

PROBLEM	CORRECTIVE ACTION
Engine will not start	<ol style="list-style-type: none"> 1. Fill fuel tank with fresh gasoline/oil mix 2. Move throttle lever to the FAST position 3. Press primer three (3) times 4. Spark plug <ul style="list-style-type: none"> • Connect spark plug wire • Clean spark plug, check spark plug gap, replace if damaged • Charge battery (model 10547)
Engine starts hard or loses power	<ol style="list-style-type: none"> 1. Move the throttle lever to the FAST position. 2. Drain and refill fuel tank with fresh gasoline/oil mix 3. Clean gas cap vent hole 4. Clean or replace air filter element 5. Clean mower discharge chute 6. Clean underside of mower deck 7. Clean spark plug, check spark plug gap, replace if damaged
Engine runs rough	<ol style="list-style-type: none"> 1. Connect spark plug wire 2. Clean spark plug, check spark plug gap, replace if damaged 3. Move throttle lever to the FAST position 4. Clean or replace air filter element

PROBLEM	CORRECTIVE ACTION
Mower or engine vibrates excessively	<ol style="list-style-type: none"> 1. Balance blade 2. Tighten blade mounting nut 3. Clean mower discharge chute 4. Clean underside of mower deck 5. Tighten engine mounting bolts
Uneven cutting pattern	<ol style="list-style-type: none"> 1. Place all four (4) wheels at same height 2. Sharpen and balance blade 3. Change mowing pattern 4. Clean underside of mower deck
Discharge chute plugs	<ol style="list-style-type: none"> 1. Move throttle lever to the FAST position 2. Raise cutting height 3. Allow grass to dry before mowing 4. Clean underside of mower deck
Will not self-propel	<ol style="list-style-type: none"> 1. Adjust self-propelled cable

Accessories

Optional accessories may have been shipped with your mower or are available from your Authorized Lawn-Boy Dealer. For proper installation follow these instructions.



m-3833

Figure 38

1. Spark plug wire

Rear Grass Catcher

! **WARNING** !

POTENTIAL HAZARD

- An uncovered discharge opening will allow objects to be thrown in operator's or bystander's direction. Also, contact with blade could occur.

WHAT CAN HAPPEN

- Thrown objects or blade contact can cause serious injury.


HOW TO AVOID THE HAZARD

- Never operate mower unless cover plate, mulch plate or grass chute and catcher are installed.

1. Stop engine and disconnect spark plug wire (Fig. 38) before installing or removing grass chute.

2. Place chute assembly into housing opening (Fig. 39).

Two shoulder bolts on the mower housing protrude through slotted holes in the chute assembly and do not have to be loosened or removed. Chute assembly moves over the shoulder bolts.



1725/1014

Figure 39

1. Chute assembly
2. Shoulder bolts
3. Knob

3. Insert chute support rod through hole at right rear of deck (Fig. 40).




Figure 40

1. Chute support rod

4. Slide chute assembly in a clockwise direction to install or counterclockwise to remove.
5. Secure chute assembly to housing with a knob (Fig. 39).
6. Remove knob and bolt securing left side upper and lower handle sections (Fig. 41).




Figure 41

1. Knob
2. Bolt
3. Hanger clamp
4. Bag hanger

7. Hold hanger clamp on outside of handle sections. Insert handle bolt from inside of handle sections through holes in hanger clamp.
8. Position bag hanger leg into hanger clamp groove and secure with knob. Repeat steps and assemble clamp and hanger to right side handle sections.
9. Close rear of bag by folding sides in and pressing interlocking rear handle halves together (Fig. 42).




Figure 42

10. Position rear bag handles into bag hanger on handle.
11. Grasp bag assembly handle and slide over flange of grass chute (Fig. 43). Push downward on handle until it seats into position.




Figure 43

Bag Adjustment

When handle height is changed bag adjustment may be required. A properly adjusted bag should be taut on top cloth area between front bag handle and rear bag hanger handles. If bag is too tight or too loose, adjust as follows:

1. Remove bag from rear bag hanger. Remove bolt(s) and knob(s) securing hanger clamps to handle sections (Fig. 44). Hanger clamps have four adjustment holes.




Figure 44

1. Knob
2. Bolt
3. Hanger clamp
4. Bag hanger

2. Reassemble hanger clamps to handle sections using whichever set of holes best holds bag taut. Using lower holes in hanger clamps tighten bag assembly and upper holes in hanger clamps loosen bag assembly.

Note: Under normal use, bag materials are subject to deterioration and wear. Check grass bag often and replace when necessary with an original equipment replacement bag. A weakened or inferior bag may let objects pass through, causing injury.

! **WARNING** !

POTENTIAL HAZARD

- Keep hands, sticks or other objects out of grass chute while blade is turning.

WHAT CAN HAPPEN

- Thrown objects or blade contact can cause serious injury.

HOW TO AVOID THE HAZARD

- Always stop engine when emptying grass bag and disconnect spark plug wire before cleaning a clogged chute, bag tunnel or underside of mower housing.

3. Reconnect spark plug wire.

Mulch Plate

! **WARNING** !

POTENTIAL HAZARD

- An uncovered discharge opening will allow objects to be thrown in operator's or bystander's direction. Also, contact with blade could occur.

WHAT CAN HAPPEN

- Thrown objects or blade contact can cause serious injury.

HOW TO AVOID THE HAZARD

- Never operate mower unless cover plate, mulch plate or grass chute and catcher are installed.

1. Stop engine and disconnect spark plug wire (Fig. 38) before installing or removing mulch plate.
2. Insert mulch plate into housing opening (Fig. 45).




Figure 45

1. Mulch plate

1123

3. Two shoulder bolts on the housing protrude through slotted holes in the mulch plate and do not have to be loosened or removed (Fig. 46). Mulch plate moves over the shoulder bolt heads.




Figure 46


1. Mulch plate
2. Shoulder bolts
3. Knob

m-1727

4. Slide mulch plate clockwise to install or counterclockwise to remove.
5. Secure with knob (Fig. 46).
6. Reconnect spark plug wire.

Note: Use only Lawn-Boy original equipment or Lawn-Boy replacement cutting blade. Other blades may strike mulch plate when engine is started and run.

Mulching Operation

Set engine speed control to MULCH ZONE . Full RPM provides the best possible mulching of grass and leaves.



To achieve the best mulching action set mower height of cut so no more than 1/3 of grass stem is cut off; maximum of 1 inch (25 mm) long clippings. If you attempt to mulch more or if grass is very lush, mulching action will be poor. Under these conditions it may be beneficial to use side discharge or catch grass clippings instead of mulching. A few days later a pass with the mulch plate installed will put you back on schedule.

Storage

To prepare lawn mower for off-season storage perform recommended maintenance procedures. See MAINTENANCE section.

Store mower in a cool place.

Fuel

 WARNING 	
POTENTIAL HAZARD	
<ul style="list-style-type: none">• In certain conditions gasoline is extremely flammable and highly explosive.	
WHAT CAN HAPPEN	
<ul style="list-style-type: none">• A fire or explosion from gasoline can burn you, others, and cause property damage.	
HOW TO AVOID THE HAZARD	
<ul style="list-style-type: none">• Do not store gasoline (fuel) over long periods of time.• To prevent possible explosion of vaporized fuel, do not store mower with fuel in the tank or carburetor in an enclosure with an open flame. (Example: furnace or water heater pilot light.)• Allow the engine to cool before storing in any enclosure.	

We recommend Lawn-Boy 2 + 4 Fuel Conditioner to stabilize fuel for storage (Fig. 47). If possible, the last fuel fill of the year should be treated with Lawn-Boy 2 + 4 Fuel Conditioner.



Figure 47

1058

Plan ahead and try to run the fuel tank empty when mowing the last time prior to storage. The smaller the amount of fuel in the tank, the shorter the time required to run the fuel system dry. Run mower until engine stops from lack of fuel.

Engine

1. Remove spark plug. Using an oil can, squirt about one tablespoon of oil through spark plug hole.
2. Slowly rotate engine several times, using starter rope, to distribute oil (Fig. 48).




Figure 48

1049

1. Starter rope

3. Replace spark plug but DO NOT connect spark plug wire.

Folding Handle

1. Remove handle mounting hardware from handle brackets (Fig. 49).

Note: Save handle mounting hardware, replace in handle bracket holes.




Figure 49

2. Rotate handle toward front of mower (Fig. 50).

Note: Fold handle only as illustrated. If handle is folded in opposite direction damage will occur to control cables.




Figure 50

1. Knob
2. Top handle half

3. Loosen knobs securing top handle section to bottom section and fold top handle section back towards rear of mower into storage position.

Removing From Storage

1. Unfold handle. See ASSEMBLY chapter, Handle section.
2. Check and tighten all fasteners.
3. Remove spark plug (Fig. 51) and spin engine rapidly using starter to blow excess oil from the cylinder. Clean spark plug or replace if cracked, broken or electrodes are worn.




Figure 51

1. Spark plug wire
-
4. Install spark plug and torque to 180 in.-lbs. (15 ft.-lbs.) (20 N·m).
 5. Perform recommended maintenance procedures. See MAINTENANCE section.
 6. Fill fuel tank (Fig. 52) with fresh, clean gasoline/oil mix.




Figure 52

7. Reconnect spark plug wire (Fig. 51).

Federal Emission Control Warranty Statement

A Two Year Limited Warranty

Your Warranty Rights and Obligations

The U.S. Environmental Protection Agency (EPA) and Lawn-Boy are pleased to explain the emission control system warranty on your 1997 and later utility/lawn/garden equipment engine. 1997 and later model year utility/lawn/garden equipment engines must be designed, built and equipped, at the time of sale, to meet the U.S. EPA regulations for small nonroad engines. The equipment engine must be free from defects in materials and workmanship which cause it to fail to conform with U.S. EPA standards for the first two years of engine use from the date of sale to the ultimate purchaser. Lawn-Boy must warrant the emission control system on your utility/lawn/garden equipment engine for the period of time listed above provided there has been no abuse, neglect or improper maintenance of your utility/lawn/garden equipment engine.

Your emission control system may include parts such as the carburetor or fuel injection system, the ignition system, and catalytic converter. Also included may be hoses, belts, and connectors and other emission related assemblies.

Where a warrantable condition exists, Lawn-Boy will repair your engine at no cost to you including diagnosis, parts and labor.

Manufacturer's Warranty Coverage:

The 1997 and later utility/lawn/garden equipment engines are warranted for two years from the date of delivery. If any emission-related part on your engine is defective in materials or workmanship, the part will be repaired or replaced by Lawn-Boy free of charge.

Owner's Warranty Responsibilities:

- As the engine owner, you are responsible for the performance of the required maintenance listed in your owner's manual. Lawn-Boy recommends that you retain all receipts covering maintenance on your equipment, but Lawn-Boy cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.
- Any replacement part or service that is equivalent in performance and durability may be used in non-warranty maintenance or repairs, and shall not reduce the warranty obligations of the engine manufacturer.
- As the engine owner, you should, however, be aware that Lawn-Boy may deny you warranty coverage if your engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications or parts.
- You are responsible for presenting your equipment engine to a LAWN-BOY Service Dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.
- If you have any questions regarding your warranty rights and responsibilities or if you need a referral to a Lawn-Boy Service Dealer, please feel free to contact us at the following address:

Lawn-Boy Customer Service Department
8111 Lyndale Avenue South
Bloomington, MN 55420-1196
612-888-8801
800-348-2424

Warranted Parts:

The warranty period begins on the date the engine or equipment is delivered to a retail purchaser. The manufacturer warrants to the initial owner and each subsequent purchaser that the engine is free from defects in materials and workmanship which cause the engine to fail to conform with applicable regulations for a period of two years.

Failures caused by abuse, neglect, or improper maintenance are not covered. The use of add-on or modified parts can be grounds for disallowing a warranty claim. The manufacturer is not liable to cover failures of warranted parts caused by the use of add-on or modified parts. Lawn-Boy is liable for damages to other engine components caused by the failure of a warranted part still under warranty. The owner is responsible for the performance of the required maintenance, as defined by the manufacturer in the written instructions.

Any warranted part which is not scheduled for replacement as required maintenance, or which is scheduled only for regular inspection to the effect of "repair or replace as necessary" shall be warranted for the warranty period. Any warranted part which is scheduled for replacement as required maintenance shall be warranted for the period of time up to the first scheduled replacement point for that part. Coverage under this warranty extends only to the parts listed below (the emissions system parts) to the extent that these parts were present on the engine when purchased.

- Fuel Metering System
 - Cold start enrichment system including the choke mechanism or priming system
 - Fuel pump
 - Air fuel ratio feed back system
 - Carburetor and internal parts
 - Fuel injection system

- Air Induction System
 - Air cleaner
 - Reed intake system
 - Intake manifold
 - Controlled hot air intake system

- Ignition System
 - Spark plug(s)
 - Ignition coils and electronics
 - Advance/retard mechanisms

- Catalytic Converter/Thermal Reactor System
 - Catalytic converter
 - Thermal reactor
 - Exhaust manifold

- Air Injection System
 - Air injection system or pulse valve
 - Valves affecting distribution of air

- Exhaust Gas Recirculation (EGR) System
 - EGR valve body and piping system connecting to the intake side of the engine
 - EGR control system

- Particulate Controls
 - Traps filters, precipitators and any other device used to capture particulate emissions

- Miscellaneous Items Used in the Above Systems
 - Vacuum, temperature, and time sensitive valves and switches
 - Electronic controls
 - Hoses, connectors, and assemblies of same

How to Get Warranty Service:

Should you feel your Lawn-Boy Product requires warranty service, contact the dealer who sold you the product or any Authorized Lawn-Boy Service Dealer or Lawn-Boy Master Service Dealer. The Yellow Pages of your telephone directory is a good reference source. The dealer will either arrange service at his/her dealership or recommend another Authorized Service Dealer who may be more convenient. You may need proof of purchase (copy of registration card, sales receipt, etc.) for warranty validation. The owner shall not be charged for diagnostic labor which leads to the determination that a warranted part is defective, if the diagnostic work is performed at a warranty station.

The Lawn-Boy Company is not liable for indirect, incidental or consequential damages in connection with the use of the Lawn-Boy Products covered by this warranty, except for damages to other engine components caused by the failure of a warranted part still under warranty. Some states do not allow exclusions of incidental or consequential damages, so the above exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



Gold Series WPM

THE LAWN-BOY NO-WORRY WARRANTY

A Full Warranty
(Limited Warranty for Commercial Use)

What Is Covered By This Express Warranty?

For a period of 2 years from the date of purchase, Lawn-Boy promises to repair any Lawn-Boy Product used for normal residential purposes* if defective in materials or workmanship or if it stops functioning due to the failure of a component.

The cost of parts and labor is included, but the customer pays the transportation costs.

What Products Are Covered By This Warranty?

This warranty applies to all Gold Series Walk Power Mowers.

How About Commercial Use?

Lawn-Boy Walk Power Mowers used for commercial, institutional or rental use are warranted against defects in material or workmanship. Components failing due to normal wear are not covered by this warranty. The following time periods apply from the date of purchase:

- Commercial Series Mowers 1 year
- All other Lawn-Boy mowers 45 days

How Do You Get Warranty Service?

Should you feel your Lawn-Boy Product requires warranty service, contact the dealer who sold you the product or any Authorized Lawn-Boy Service Dealer. The Yellow Pages of your telephone directory is a good reference source. The dealer will either arrange service at his/her dealership or recommend another Authorized Service Dealer who may be more convenient. You may need proof of purchase (copy of registration card, sales receipt, etc.) for warranty validation.

If for any reason you are dissatisfied with the Service Dealer's analysis of the defect in materials or workmanship or if you need a referral to a Lawn-Boy Service Dealer, please feel free to contact us at the following address:

Lawn-Boy Customer Service Department
8111 Lyndale Avenue South
Bloomington, MN 55420-1196
612-888-8801
800-526-6937

What Must You Do To Keep The Warranty In Effect?

You must maintain your Lawn-Boy Product by following the maintenance procedures described in the operator's manual. Such routine maintenance, whether performed by a dealer or by you, is at your expense.

What Does This Warranty Not Cover? and

How Does Your State Law Relate To This Warranty?

There is no other express warranty except for special emission system coverage on some products. This express warranty does not cover:

- Cost of regular maintenance service or parts, such as filters, fuel, lubricants, oil changes, spark plugs, blade sharpening, blade worn out, cable/linkage adjustments or brake and clutch adjustments.
- Any product or part which has been altered or misused or required replacement or repair due to accidents or lack of proper maintenance.
- Repairs necessary due to improper fuel, contaminants in the fuel system, or failure to properly prepare the fuel system prior to any period of non-use over three months.
- Repairs necessary due to improper battery care, electrical supply irregularities, or failure to properly prepare the mower prior to any period of non-use.
- Pickup and delivery charges.

All repairs covered by this warranty must be performed by an Authorized Lawn-Boy Service Dealer using Lawn-Boy approved replacement parts.

Repair by an Authorized Lawn-Boy Service Dealer is your sole remedy under this warranty.

Lawn-Boy is not liable for indirect, incidental or consequential damages in connection with the use of the Lawn-Boy Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Some states do not allow exclusions of incidental or consequential damages, so the above exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

* Normal residential purposes means mowing the lawn on the same lot as your home. Use at more than one location is considered commercial use and the commercial use warranty would apply.

COUNTRIES OTHER THAN THE UNITED STATES

Customers who have purchased Lawn-Boy Products exported from the United States should contact their Lawn-Boy Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the Lawn-Boy importer. If all other remedies fail, you may contact us at Lawn-Boy.