

LAWN-BOY®

21" GOLD SERIES WALK-BEHIND MOWER

HAND PUSH

MODEL NO.10415-3900001 & UP

MODEL NO.10420-3900001 & UP

SELF PROPELLED

MODEL NO.10515-3900001 & UP

MODEL NO.10520-3900001 & UP

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product has two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the back side of the control panel. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.


NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
2 Cycle Engine, Fuel Tank And Blade Assembly	1	Gear Case Assembly	5
Deck And Wheel Assembly (Hand Push) Model No. 10415 & 10420	2	Handle Assembly	6
Deck And Wheel Assembly (Self Propelled) Model No.10515 & 10520	3	Starter Assembly (Pull)	7
Rear Axle Assembly Model No..10515 & 10520	4	Engine Assembly (Hand Push)	8
		Engine Assembly (Self Propelled)	10
		Carburetor Assembly	12
		Lawn-Boy Numeric Index	14

Accessories

Description	Model / Parts No.	Description	Model / Parts No.
Cover Plate, Mulch	614545 or 89864	Leaf Bag	684075 or 89818
Cover Plate, Side Discharge	60560	Leaf Shredder Attachment	681684 or 89860
Rear Catcher Assembly	684690 or 89800	Note:	
Side Catcher Assembly	89816	Your Model Lawnmower may have been purchased with one or more accessories	
Side Bag Chute	683792 or 89852		
use with leaf bag			




ENGINE, FUEL TANK & BLADE ASSEMBLY

C-1324

Ref. No.	Part No.	Description	No. Used
1	306531	Nut	1
2	611213	Retainer	1
3	611509	Actuator - Lever Brake	1
4	611214	Spring	1
5	92-1084	Shroud & Tank Assembly	1
6	684301	Base - Starter	1
7	683896	Starter Assembly	1
8	611395	Screw - Self Tapping	5
9	612428	Screw	4
10	47-2480	Stop - Rope	1
11	611327	Cap - Fuel	1
12	607213	Gasket - Fuel Cap	1
13	609150	Baffle Fuel Cap	1
14	605120	Grommet	1
15	92-1645	Decal - Recoil (Hand Push)	1
*	92-1644	Decal - Recoil (Self Propelled).	1

Ref. No.	Part No.	Description	No. Used
16		Engine Assembly	1
17	612783	Line - Fuel	1
18	612974	Screen - Fuel Line	1
19	314576	Screw	1
20	677525	Plate & Collar Assembly	1
21	612543	Blade 21"	1
22	92-1630	Fan - Mulching	1
23	603164	Nut - Blade	1
24	92-1648	Screw - Engine	3
25	682876	Muffer Cover Assembly	1
26	609786	Support - Crankshaft	1
27	609471	Screw	3
28	611802	Plate - Muffer	1
29	613500	Screw	1
30	607601	Screw	3
31	609420	Gasket - Muffer	1




C-1325

DECK AND WHEEL ASSEMBLY (Hand Push)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	614545	Cover - Plate, Mulch	1	14	92-4856	Bolt - Shoulder	2
*	607560	Cover - Side Discharge Note: See Page i Accessories. Some model lawnmower may have one or more accessories	1	15	92-1604	Hub Cap	4
2	604604	Grommet	3	16	614650	Bolt - Wheel	2
3	614677	Screw - Thread Forming	2	17	684777	Wheel Assembly 8"	2
4	614682	Knob	1	18	40-1940	Washer - Wheel Bolt	4
5	39-5770	Decal - Danger (English)	1	19	614637	Bracket - H. O. C.	4
*	92-5429	Decal - Danger (French /English)	1	20	603620	Washer	2
6	92-1032	Bracket - Handle, R.H.	1	21	322-45	Screw	6
8	92-4875	Shield - Trailing	1	22	3296-29	Nut - Lock	6
9	32121-61	Pin - Roll	2	23	92-1008	Knob - Spring Arm	4
10	92-4893	Decal - H. O. C. L.H.	2	24	92-1006	Spring Arm Assembly	2
*	92-4892	Decal - H. O. C. R.H.	2	25	684776	Wheel - 6"	2
11	92-1031	Bracket - Handle	1	26	92-1099	Bolt - Wheel	2
12	92-1005	Spring Arm Assembly	2	27	67-9760	Washer	2
13	3290-413	Washer - Belleville	4	28	46-6811	Screw	2
				29	608175	Bar - Toe	
				30	614701	Applique	1
				31	16-2019	Housing - 21" (Incl. Ref.#5 &30)	1
				32	3296-39	Nut - Lock	4

*Not Illustrated




C-1326

DECK AND WHEEL ASSEMBLY (Self Propelled)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	614545	Cover- Plate, Mulch	1	15	32121-61	Pin - Roll	2
*	607560	Cover - Side Discharge Note: See Page i Accessories. Some model lawnmower may have one or more accessories	1	16	322-45	Screw	6
2	604604	Grommet	3	17	92-4875	Shield - Trailing	1
3	614677	Screw - Thread Forming	2	18	3296-29	Nut - Lock	6
4	614682	Knob	1	19	92-1008	Knob - Spring Arm	4
5	39-5770	Decal - Danger (English)	1	20	92-1006	Spring Arm Assembly	2
*	92-5429	Decal - Danger (French /English)	1	21	3290-413	Washer - Belleville	2
6	92-1030	Bracket - Handle, R.H.	1	22	92-4856	Bolt - Shoulder	2
7	926641	Screw	2	23	684776	Wheel - 6"	2
8	92-1620	Cover - Drive	1	24	92-1099	Bolt - Wheel	2
9	49-2040	Screw	2	25	92-1604	Hub Cap	4
10	92-1618	Bracket - Actuator	1	26	40-1940	Washer - Wheel Bolt	2
12	92-1636	Gear Case Assembly	1	27	614637	Bracket - H. O. C.	2
13	92-1029	Bracket - Handle, L.H.	1	28	67-9760	Washer	2
14	92-2917	Decal - H. O. C. L.H.	1	29	46-6811	Screw	2
*	92-2916	Decal - H. O. C. R.H.	1	30	608175	Bar- Toe	1
				31	614701	Applique	1
				32	16-2029	Housing - 21 (Incl. Ref. #5 & 31)	1
				33	3296-39	Nut - Lock	2


*Not Illustrated



REAR WHEEL DRIVE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1		Knob - Spring Arm (Ref.)	2
2	92-1004	Spring Arm Assembly	2
3	70-9760	Bushing	2
4	684616	Pivot Arm Assembly	2
5		Fitting - Grease (Ref.)	2
6	47-2900	Bushing	2
7	65-4730	Washer - Thrust	2
8	65-4740	Washer - Thrust	4
9	65-4710	Ring - Friction	2
10	65-4760	Washer - Clutch	2
11	66-6050	Key - Rocking, L. H.	1
*	66-6040	Key - Rocking, R. H.	1
12	65-4750	Gear - Pinion	2
13	614426	Washer - Stepped	2
14	92-1042	Wheel - 8"	2
15	92-1057	Bolt - Wheel	2


Ref. No.	Part No.	Description	No. Used
16	614427	Cover - Wheel	2
17	65-2720	Ring - Retaining	4
18	65-4720	Spring - Compression	2
19	32144-70	Screw - Hex. Hd.	1
20	82-8780	Retainer - Cable	1
21	60-8821	Lever - Shift	1
22	3296-56	Nut	2
23	3272-10	Pin - Cotter	1
24	610358	Nut	2
25	602480	Screw	2
26	614447	Spacer - Axle	2
27	614443	Ring - Isolation	2
28	92-1043	"V" Belt	1
29	605255	Washer - Felt	1
30	303259	Washer - Flat	1
31	24-7920	Cover - Drive Shaft	1



C-1322

GEAR CASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	32121-120	Pin - Coil	1	17	36-4780	Washer	1
2	38-7820	Bearing - Ball	2	18	60-8770	Bushing - Output	1
3	60-8850	Bushing - Output	1	19	60-8750	Bushing - inter. Shaft	2
4	65-4770	Shaft - Output	1	20	36-4791	Washer - Thrust	2
5	62-6660	Spacer	1	21	49-2040	Screw	6
6	60-8840	Pulley - Half	2	22	60-8730	Gear Case Cover	
7	3296-5	Nut	1	23	55-3760	Pinion - 15 Tooth	1
8	3256-24	Washer	1	24	55-3780	Pinion - 20 Tooth	1
9	92-1076	Gearcase - Upper	1	25	55-3800	Pinion - 25 Tooth	1
10	60-8870	Yoke - Shift	1	26	60-8800	Shaft - Intermediate	1
11	29-9570	Bushing - Yoke	1	27	92-1075	Bevel Pinion	1
12	60-8810	Retainer - Shift Fork	1	28	55-3770	Gear - 49 Tooth	1
13	76-0780	Sleeve - Shift Key	1	29	55-3790	Gear - 44 Tooth	1
14	76-0760	Key - Shift	2	30	55-3810	Gear - 39 Tooth	1
15	76-0770	Collar - Shift	1	31	60-8790	Sleeve - Gear	1
16	65-5250	Clip - Spring	1				




C-1327

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-2268	Screw	2
2	92-2930	Guide - Rope	1
3		Rope - Starter	1
4	612825	Handle - Rope	1
5	92-2918	Decal - Control Panel	1
6	92-1633	Cable - Brake	1
7	16-2049	Panel - Control (Self Propelled)	1
		Incl. Ref.#10,11)	
*	16-2039	Panel - Control (Hand Push)	1
		Incl. Ref.#10,11)	
8	92-1093	Bail - Brake	1
9	92-2922	Control Ground Speed (Self Propelled)	1
10	92-2940	Decal - Warning(Engilsh)	1
*	92-5427	Decal - Warning (French/English)	1
11	92-1623	Decal - Control Panel (Self Propelled English)	1
*	92-5426	Decal - Control Panel (Hand Push French English)	1
*	92-2902	Decal - Control Panel (Hand Push English)	1
*	92-5430	Decal - Control Panel (Hand Push French English)	1

Ref. No.	Part No.	Description	No. Used
12	92-1643	Control - Throttle	1
13	32144-115	Screw	4
14	612824	Insert - Handle	1
15	92-1617	Bail - Control (Self Propelled)	1
16	614679	Stop - Pivot (Self Propelled)	1
17	3296-73	Nut	3
18	92-1094	Bracket - Cam	1
19	92-1078	Brake - BBC Cam	1
20	614697	Screw - Handle	2
21	92-1092	Handle - Upper	1
22	614243	Knob - Handle	2
23	613050	Bolt - Shoulder	1
24	321-4	Screw - Hex. Hd.	1
25	614249	Tie - Cable	2
26	3230-28	Bolt - Carriage	2
27	92-2920	Handle - Lower	1
28	92-1631	Cable - Traction (Self Propelled)	1
29	92-1095	Bracket - Traction Cable (Self Propelled)	1
30	3253-33	Washer	2
31	32103-29	Nut - Wing	2
32	92-2928	Bracket - Cable	1
33	3296-56	Nut	1

*Not Illustrated




C-1337

STARTER

Ref. No.	Part No.	Description	No. Used
*	683896	Starter Assembly (Incl. Ref. #5-9)	1
1	92-1645	Decal - Recoil (Hand Push)	1
*	92-1644	Decal - Recoil (Self Propelled)	1
2	684567	Starter Housing & Shaft	1

Ref. No.	Part No.	Description	No. Used
3	683897	Spring & Keeper	1
4	612825	Handle - Starter	1
5	612824	Clip - Rope	1
6	612432	Rope	1
7	612950	Pulley	1
8	612949	Hub - Starter	1
9	683899	Kit - Dog	1

ENGINE ASSEMBLY (Hand Push)




ENGINE ASSEMBLY (Hand Push)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	611213	Retainer	1	29	611396	Seal – Oil	1
2	611509	Actuator – Brake Lever	1	30	681830	Bearing – Main	1
3	611214	Spring – Cable, Return	1	31	610747	Crankshaft	1
4	683968	Switch Assembly (Incl. Ref. #1,6,20, & 56-58)	1	32	611393	Screw	2
5	682683	Brake Assembly	1	33	683911	Set – Needle Bearing	1
6	683821	Wire Lead	1	34	607526	Screw	2
7	613529	Bolt – Shoulder	1	35	614008	Spark Plug	1
8	608311	Nut	1	36	684698	Cover – Terminal	1
9	683581	Brace Assembly	1	37	681678	Wire Lead	1
10	603014	Bolt	1	38	683215	C. D. Ignition Module (Incl. Ref. #36, 37)	1
11	603093	Washer	1	39	605120	Grommet	2
12	602315	Nut	1	40	614249	Tie Strap	1
13	612427	Shroud – Base	1	41	613073	Bracket – C. D.	1
14	611191	"J"Clip	1	42	614343	Screw	2
15	609947	Screw	3	43	683693	Cylinder & Crankcase Cover Assembly (Incl. Ref. #46-48,51 & 53)	1
16	683580	Flywheel Assembly	1	44	609123	Plug	4
17	316959	Washer – Lock	1	45	609420	Gasket – Exhaust	1
18	130743	Nut – Flywheel	1	46	612872	Screw	2
19	609808	Screw	2	47	602587	Plate – Reed	1
20	317893	Tie Strap	1	48	602588	Reed	1
21	681737	Set – Ring	1	49	681831	Bearing – Main	1
22	303712	Ring – Retaining	2	50	611396	Seal – Oil	1
23	606608	Pin – Wrist	1	51	613110	Screw	2
24	682677	Piston & Connecting Rod Assembly (Incl. Ref. #24-27 & 32-33)	1	52	611192	Bracket – Brake	1
*	682966	Set – Piston & Ring (Incl. Ref.# 21-23)	1	53	613233	Screw	2
25	679144	Bearing Assembly	1	54	611211	Spring – Brake	1
26	682970	Connecting Rod Assembly (Incl. Ref. #25-27,32 & 33)	1	55	683819	Case Assembly	1
27	603954	Liner – Split	1	56	306407	Washer	1
28	607199	Key – Flywheel	1	57	609891	Screw	1
				*	683700	Short Block	1

*Not Illustrated


ENGINE ASSEMBLY (Self Propelled)



ENGINE ASSEMBLY (Self Propelled)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	611396	Seal – Oil	2	19	303712	Ring – Retaining	2
2	681831	Bearing – Lower	1	20	606608	Pin – Wrist	1
3	611393	Screw	2	21	681737	Set – Ring	1
4	682970	Connecting Rod Assembly (Incl. Ref. #3,5 16 & 17)	1	22	607526	Spark Plug	1
5	677982	Liner – Split	1	23	607526	Screw	2
6	612159	Crankshaft	1	24	609651	Terminal	1
7	681830	Bearing – Upper	1	25	684678	Cover & Terminal Assembly	1
8	611522	Shroud – Base	1	26	681678	Wire Lead	1
9	609947	Screw	3	27	683215	C. D. Ignition (Incl. Ref. #25 & 26)	1
10	683855	Flywheel	1	28	605120	Grommet	2
11	316959	Washer – Lock	1	29	614249	Tie Strap	2
12	130743	Nut – Flywheel	1	30	613073	Bracket – Ignition	1
13	317893	Tie Strap	1	31	614343	Screw	2
14	609808	Screw	1	32	683708	Cylinder & Crankcase Cover (Incl. Ref. #31, 35-38)	1
15	607199	Key – Flywheel	1	33	609123	Plug – Intake	4
16	683911	Set – Needle Bearing	1	34	609420	Gasket – Exhaust	1
17	679144	Bearing Assembly	1	35	612872	Screw	2
18	682677	Piston & Connecting Rod Assembly (Incl. Ref.# 3-5,16 & 17-21)	1	36	602587	Plate – Reed	1
*	682986	Set – Piston & Ring (Incl. Ref. #19-21)	1	37	602588	Reed	1
				38	613110	Screw	4
				*	683700	Short Block	1

*Not Illustrated



C-1340

CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
*	684352	Body - Carburetor (Incl. Ref. #18-34)	1	*	684285	Kit - Idle Needle	1
1	612505	Vane - Air	1	21		Spring - Needle	1
2	605522	Screw	1	22		Needle - Idle	1
3	610165	Retainer - Speed Control Lever	1	23	683783	Kit - Float Assembly	1
4	612502	Lever - Governor Control	1	*	683782	Kit - Bowl (Incl. Ref. #24-25)	1
5	612757	Collar	1	24		Bowl - Fuel	1
6	613142	Spring	1	25		Screw	1
7	308052	Washer	1	*		Kit - Gasket	1
8	612504	Base - Air Filter	1	*	683778	Kit - Gasket (Incl. Ref. #26 & 27)	1
9	612503	Spacer - Filter Base	1	26		Gasket - Bowl Retainer	1
10	609493	Element - Air Filter	1	27		Gasket - Bowl	1
11	610742	Cover - Air Filter	1	*	683777	Kit - Repair (Incl. Ref. #28-31)	1
12	610383	Retainer - Cover	1	28		Plug - Welch	2
13	328712	Nut	1	29		Shaft - Float	1
14	314576	Screw	1	30		Inlet - Needle Valve	1
15	612974	Filter - Fuel	1	31		Seat - Valve	1
16	613143	Heat Shield	1	*		Kit - Gasket	1
17	612507	Screw	2	*	683781	Kit - Choke (Incl. Ref. #32-34)	1
*	612783	Line - Fuel	1	32		Valve - Choke	1
*	684286	Kit - Throttle (Incl. Ref. #18-20)	1	33		Spring - Return	1
18		Shaft - Throttle	1	34		Shaft - Choke	1
19		Vane - Throttle	1	35	612574	Gasket Carburetor	2
20		Screw	1				

LAWN-BOY PART NUMBER INDEX

3315-899

Part No.	Description	Pg. Ref.			Part No.	Description	Pg. Ref.		
		No.	No.	Qty.			No.	No.	Qty.
130743	Nut - Flywheel	11	12	1	610358	Nut	4	24	2
130743	Nut - Flywheel	9	18	1	610383	Retainer - Cover	12	12	1
303259	Washer - Flat	4	30	1	610742	Cover - Air Filter	12	11	1
303712	Ring - Retaining	11	19	2	610747	Crankshaft	9	31	1
303712	Ring - Retaining	9	22	2	611191	"J"Clip	9	14	1
306407	Washer	9	56	1	611192	Bracket - Brake	9	52	1
306531	Nut	1	1	1	611211	Spring - Brake	9	54	1
308052	Washer	12	7	1	611213	Retainer	9	1	1
314576	Screw	12	14	1	611213	Retainer	1	2	1
314576	Screw	1	19	1	611214	Spring	1	4	1
316959	Washer - Lock	11	11	1	611214	Spring - Cable, Return	9	3	1
316959	Washer - Lock	9	17	1	611327	Cap - Fuel	1	11	1
317893	Tie Strap	11	13	1	611393	Screw	11	3	2
317893	Tie Strap	9	20	1	611393	Screw	9	32	2
328712	Nut	12	13	1	611395	Screw - Self Tapping	1	8	5
602315	Nut	9	12	1	611396	Seal - Oil	11	1	2
602480	Screw	4	25	2	611396	Seal - Oil	9	29	1
602587	Plate - Reed	11	36	1	611396	Seal - Oil	9	50	1
602587	Plate - Reed	9	47	1	611509	Actuator - Brake Lever	9	2	1
602588	Reed	11	37	1	611509	Actuator - Lever Brake	1	3	1
602588	Reed	9	48	1	611522	Shroud - Base	11	8	1
603014	Bolt	9	10	1	611802	Plate - Muffler	1	28	1
603093	Washer	9	11	1	612159	Crankshaft	11	6	1
603164	Nut - Blade	1	23	1	612427	Shroud - Base	9	13	1
603620	Washer	2	20	2	612428	Screw	1	9	4
603954	Liner - Split	9	27	1	612432	Rope	7	6	1
604604	Grommet	2	2	3	612502	Lever - Governor Control	12	4	1
604604	Grommet	3	2	3	612503	Spacer - Filter Base	12	9	1
605120	Grommet	1	14	1	612504	Base - Air Filter	12	8	1
605120	Grommet	11	28	2	612505	Vane - Air	12	1	1
605120	Grommet	9	39	2	612507	Screw	12	17	2
605255	Washer - Felt	4	29	1	612543	Blade 21"	1	21	1
605522	Screw	12	2	1	612574	Gasket Carburetor	12	35	2
606608	Pin - Wrist	11	20	1	612757	Collar	12	5	1
606608	Pin - Wrist	9	23	1	612783	Line - Fuel	12	*	1
607199	Key - Flywheel	11	15	1	612783	Line - Fuel	1	17	1
607199	Key - Flywheel	9	28	1	612824	Clip - Rope	7	5	1
607213	Gasket - Fuel Cap	1	12	1	612824	Insert - Handle	6	14	1
607526	Screw	11	23	2	612825	Handle - Rope	6	4	1
607526	Screw	9	34	2	612825	Handle - Starter	7	4	1
607526	Spark Plug	11	22	1	612872	Screw	11	35	2
607560	Cover - Side Discharge	2	*	1	612872	Screw	9	46	2
607560	Cover - Side Discharge	3	*	1	612949	Hub - Starter	7	8	1
607601	Screw	1	30	3	612950	Pulley	7	7	1
608175	Bar - Toe	2	29		612974	Filter - Fuel	12	15	1
608175	Bar - Toe	3	30		612974	Screen - Fuel Line	1	18	1
608311	Nut	9	8	1	613050	Bolt - Shoulder	6	23	1
609123	Plug	9	44	4	613073	Bracket - C. D.	9	41	1
609123	Plug - Intake	11	33	4	613073	Bracket - Ignition	11	30	1
609150	Baffle Fuel Cap	1	13	1	613110	Screw	11	38	4
609420	Gasket - Exhaust	11	34	1	613110	Screw	9	51	2
609420	Gasket - Exhaust	9	45	1	613142	Spring	12	6	1
609420	Gasket - Muffler	1	31	1	613143	Heat Shield	12	16	1
609471	Screw	1	27	3	613233	Screw	9	53	2
609493	Element - Air Filter	12	10	1	613500	Screw	1	29	1
609651	Terminal	11	24	1	613529	Bolt - Shoulder	9	7	1
609786	Support - Crankshaft	1	26	1	614008	Spark Plug	9	35	1
609808	Screw	11	14	1	614243	Knob - Handle	6	22	2
609808	Screw	9	19	2	614249	Tie - Cable	6	25	2
609891	Screw	9	57	1	614249	Tie Strap	11	29	2
609947	Screw	11	9	3	614249	Tie Strap	9	40	1
609947	Screw	9	15	3	614343	Screw	11	31	2
610165	Retainer - Speed	12	3	1	614343	Screw	9	42	2

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
614426	Washer - Stepped	4	13	2	684352	Body - Carburetor	12	*	1
614427	Cover - Wheel	4	16	2	684567	Starter Housing & Shaft	7	2	1
614443	Ring - Isolation	4	27	2	684616	Pivot Arm Assembly	4	4	2
614447	Spacer - Axle	4	26	2	684678	Cover & Terminal Assembly	11	25	1
614545	Cover - Plate, Mulch	2	1	1	684698	Cover - Terminal	9	36	1
614545	Cover - Plate, Mulch	3	1	1	684776	Wheel - 6"	3	23	2
614637	Bracket - H. O. C.	2	19	4	684776	Wheel - 6"	2	25	2
614637	Bracket - H. O. C.	3	27	2	684777	Wheel Assembly 8"	2	17	2
614650	Bolt - Wheel	2	16	2	926641	Screw	3	7	2
614677	Screw - Thread Forming	2	3	2	16-2019	Housing - 21"	2	31	1
614677	Screw - Thread Forming	3	3	2	16-2029	Housing - 21"	3	32	1
614679	Stop - Pivot	6	16	1	16-2039	Panel - Control	6	*	1
614682	Knob	2	4	1	16-2049	Panel - Control	6	7	1
614682	Knob	3	4	1	24-7920	Cover - Drive Shaft	4	31	1
614697	Screw - Handle	6	20	2	29-9570	Bushing - Yoke	5	11	1
614701	Applique	2	30	1	36-4780	Washer	5	17	1
614701	Applique	3	31	1	36-4791	Washer - Thrust	5	20	2
677525	Plate & Collar Assembly	1	20	1	38-7820	Bearing - Ball	5	2	2
677982	Liner - Split	11	5	1	39-5770	Decal - Danger	2	5	1
679144	Bearing Assembly	11	17	1	39-5770	Decal - Danger	3	5	1
679144	Bearing Assembly	9	25	1	40-1940	Washer - Wheel Bolt	2	18	4
681678	Wire Lead	11	26	1	40-1940	Washer - Wheel Bolt	3	26	2
681678	Wire Lead	9	37	1	46-6811	Screw	2	28	2
681737	Set - Ring	11	21	1	46-6811	Screw	3	29	2
681737	Set - Ring	9	21	1	47-2480	Stop - Rope	1	10	1
681830	Bearing - Main	9	30	1	47-2900	Bushing	4	6	2
681830	Bearing - Upper	11	7	1	49-2040	Screw	3	9	2
681831	Bearing - Lower	11	2	1	49-2040	Screw	5	21	6
681831	Bearing - Main	9	49	1	55-3760	Pinion - 15 Tooth	5	23	1
682677	Piston & Connecting Rod	11	18	1	55-3770	Gear - 49 Tooth	5	28	1
682677	Piston & Connecting Rod	9	24	1	55-3780	Pinion - 20 Tooth	5	24	1
682683	Brake Assembly	9	5	1	55-3790	Gear - 44 Tooth	5	29	1
682876	Muffler Cover Assembly	1	25	1	55-3800	Pinion - 25 Tooth	5	25	1
682966	Set - Piston & Ring	9	*	1	55-3810	Gear - 39 Tooth	5	30	1
682970	Connecting Rod Assembly	11	4	1	60-8730	Gear Case Cover	5	22	
682970	Connecting Rod Assembly	9	26	1	60-8750	Bushing - Inter. Shaft	5	19	2
682986	Set - Piston & Ring	11	*	1	60-8770	Bushing - Output	5	18	1
683215	C. D. Ignition	11	27	1	60-8790	Sleeve - Gear	5	31	1
683215	C. D. Ignition Module	9	38	1	60-8800	Shaft - Intermediate	5	26	1
683580	Flywheel Assembly	9	16	1	60-8810	Retainer - Shift Fork	5	12	1
683581	Brace Assembly	9	9	1	60-8821	Lever - Shift	4	21	1
683693	Cylinder & Crankcase Cover	9	43	1	60-8840	Pulley - Half	5	6	2
683700	Short Block	11	*	1	60-8850	Bushing - Output	5	3	1
683700	Short Block	9	*	1	60-8870	Yoke - Shift	5	10	1
683708	Cylinder & Crankcase Cover	11	32	1	62-6660	Spacer	5	5	1
683777	Kit - Repair	12	*	1	65-2720	Ring - Retaining	4	17	4
683778	Kit - Gasket	12	*	1	65-4710	Ring - Friction	4	9	2
683781	Kit - Choke	12	*	1	65-4720	Spring - Compression	4	18	2
683782	Kit - Bowl	12	*	1	65-4730	Washer - Thrust	4	7	2
683783	Kit - Float Assembly	12	23	1	65-4740	Washer - Thrust	4	8	4
683819	Case Assembly	9	55	1	65-4750	Gear - Pinion	4	12	2
683821	Wire Lead	9	6	1	65-4760	Washer - Clutch	4	10	2
683855	Flywheel	11	10	1	65-4770	Shaft - Output	5	4	1
683896	Starter Assembly	7	*	1	65-5250	Clip - Spring	5	16	1
683896	Starter Assembly	1	7	1	66-6040	Key - Rocking, R. H.	4	*	1
683897	Spring & Keeper	7	3	1	66-6050	Key - Rocking, L. H.	4	11	1
683899	Kit - Dog	7	9	1	67-9760	Washer	2	27	2
683911	Set - Needle Bearing	11	16	1	67-9760	Washer	3	28	2
683911	Set - Needle Bearing	9	33	1	70-9760	Bushing	4	3	2
683968	Switch Assembly	9	4	1	76-0760	Key - Shift	5	14	2
684285	Kit - Idle Needle	12	*	1	76-0770	Collar - Shift	5	15	1
684286	Kit - Throttle	12	*	1	76-0780	Sleeve - Shift Key	5	13	1
684301	Base - Starter	1	6	1	82-8780	Retainer - Cable	4	20	1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref.			Part No.	Description	Pg. Ref.		
		No.	No.	Qty.			No.	No.	Qty.
92-1004	Spring Arm Assembly	4	2	2	92-2917	Decal - H. O. C. L.H.	3	14	1
92-1005	Spring Arm Assembly	2	12	2	92-2918	Decal - Control Panel	6	5	1
92-1006	Spring Arm Assembly	3	20	2	92-2920	Handle - Lower	6	27	1
92-1006	Spring Arm Assembly	2	24	2	92-2922	Control Ground Speed	6	9	1
92-1008	Knob - Spring Arm	3	19	4	92-2928	Bracket - Cable	6	32	1
92-1008	Knob - Spring Arm	2	23	4	92-2930	Guide - Rope	6	2	1
92-1029	Bracket - Handle, L.H.	3	13	1	92-2940	Decal - Warning	6	10	1
92-1030	Bracket - Handle, R.H.	3	6	1	92-4856	Bolt - Shoulder	2	14	2
92-1031	Bracket - Handle	2	11	1	92-4856	Bolt - Shoulder	3	22	2
92-1032	Bracket - Handle, R.H.	2	6	1	92-4875	Shield - Trailing	2	8	1
92-1042	Wheel - 8"	4	14	2	92-4875	Shield - Trailing	3	17	1
92-1043	VBelt	4	28	1	92-4892	Decal - H. O. C. R.H.	2	*	2
92-1057	Bolt - Wheel	4	15	2	92-4893	Decal - H. O. C. L.H.	2	10	2
92-1075	Bevel Pinion	5	27	1	92-5426	Decal - Control Panel	6	11	1
92-1076	Gearcase - Upper	5	9	1	92-5427	Decal - Danger	6	10	1
92-1078	Brake - BBC Cam	6	19	1	92-5429	Decal - Danger	2	5	1
92-1084	Shroud & Tank Assembly	1	5	1	92-5429	Decal - Danger	3	5	1
92-1092	Handle - Upper	6	21	1	92-2930	Decal - Control Panel	6	11	1
92-1093	Bail - Brake	6	8	1	321-4	Screw - Hex. Hd.	6	24	1
92-1094	Bracket - Cam	6	18	1	322-45	Screw	3	16	6
92-1095	Bracket - Traction Cable	6	29	1	322-45	Screw	2	21	6
92-1099	Bolt - Wheel	3	24	2	3230-28	Bolt - Carriage	6	26	2
92-1099	Bolt - Wheel	2	26	2	3253-33	Washer	6	30	2
92-1604	Hub Cap	2	15	4	3256-24	Washer	5	8	1
92-1604	Hub Cap	3	25	4	3272-10	Pin - Cotter	4	23	1
92-1617	Bail - Control	6	15	1	3290-413	Washer - Belleville	2	13	4
92-1618	Bracket - Actuator	3	10	1	3290-413	Washer - Belleville	3	21	2
92-1620	Cover - Drive	3	8	1	3296-5	Nut	5	7	1
92-1623	Decal - Control Panel,	6	11	1	3296-29	Nut - Lock	3	18	6
92-1630	Fan - Mulching	1	22	1	3296-29	Nut - Lock	2	22	6
92-1631	Cable - Traction	6	28	1	3296-39	Nut - Lock	2	32	4
92-1633	Cable - Brake	6	6	1	3296-39	Nut - Lock	3	33	2
92-1636	Gear Case Assembly	3	12	1	3296-56	Nut	4	22	2
92-1643	Control - Throttle	6	12	1	3296-56	Nut	6	33	1
92-1644	Decal - Recoil	1	*	1	3296-73	Nut	6	17	3
92-1644	Decal - Recoil	7	*	1	32103-29	Nut - Wing	6	31	2
92-1645	Decal - Recoil	7	1	1	32121-61	Pin - Roll	2	9	2
92-1645	Decal - Recoil	1	15	1	32121-61	Pin - Roll	3	15	2
92-1648	Screw - Engine	1	24	3	32121-120	Pin - Coil	5	1	1
92-2268	Screw	6	1	2	32144-70	Screw - Hex. Hd.	4	19	1
92-2902	Decal - Control Panel	6	*	1	32144-115	Screw	6	13	4
92-2916	Decal - H. O. C. R.H.	3	*	1					

